
12V
25A
40A
50A
Starter relay block
(fuse slot is not used)
To starter on
engine
Jump-it
Connector
.3Ω
11W
** Alternator (order
doesn't matter)
AC/DC
Converter
Yellow
Red
Green
Dash E-Stop
Brake over-travel
kill switch
Brake Light
Brake Pedal Switch
Fuse 43
3A
Fuse 44
15A
Fuse 47
15A
Fuse 52
?A
Fuse 53
?A
Fuse 56
15A
Fuse 50
30A
Fuse 57
15A
Fuse 51
?A
DTA Power
Injectors
Coils
DAQ
Transponder ***
C107
Engine
Start
Pneumatics
Relay Power
DTA Pin 5
DTA Pin 5
DTA Pin 41
Fuel
Pump
Lambda Sensor
Power *#
Fan
12V Power to Dash

Pneumatics
Relay Power
(Fuse 50)
Upshift
Pneumatic
Valve
Downshift
Pneumatic
Valve
C505
Shiftcut
DTA Pin 33
Clutch
Pneumatic
Valve
Relay
12 V from Dash
*5
Steering Wheel
Buttons